

www.evotech-performance.com

Ducati Streetfighter V4 / Panigale V4

Tail Tidy Instructions

#### Installation Instructions





#### Kit Contents PRN014957

- (A) 1 x Reflector Kit
- B 1 x Support Arm
- © 1 x Connector Type 10
- D 1 x EP Number Plate Light
- E) 1 x M4 x 10 Button Head Bolt
- F) 1 x M5 x 8 Button Head Bolt
- © 2 x M4 Nuts
- (H) 2 x Indicator Adaptors
- ① 2 x M6 x 12 Button Head Bolt
- ① 2 x M5 x 16 Button Head Bolt

- (K) 2 x M5 x 70 Button Head Bolts (Double Stem Version)
- © 2 x M5 x 40 Button Head Bolts (Single Stem Version) © 2 x M5 x 12 Button Head Bolt
- N 4 x Indicator Stems
- 4 x Indicator Clamps









3

















































Second stem only required for large numberplates

























## <del>15</del>

























































## **Installation Instructions**








### **Installation Instructions**











# ESSENTIAL CHECKS 🔨



After installation of your tail tidy ensure that the licence plate does not contact the rear tyre when suspension is fully compressed. Ensure all electrics including indicators, tail light, brake light and licence plate light lights are working correctly before riding the motorcycle. It is recommended that periodic inspections are made to ensure that all fixings are fully tightend.





www.evotech-performance.com