

www.evotech-performance.com
BMW F 900 XR / TE Crash Protection
Installation Instructions

Installation Instructions





Kit Contents PRN015040


A 1 x R/H Bobbin Bracket


- M 2 x Large Bobbin Head
- 1 x R/H Front Frame Spacer (Large Location Diameter)
 № 2 x Poly Washer
- D 1 x R/H Bobbin Spacer
- E 1 x M12 x 90mm Caphead
- F 1 x L/H Bobbin Bracket
- © 1 x L/H Front Frame Spacer (Long Version)
- H 1 x L/H Rear Frame Spacer (Short Version)
- 1 x L/H Bobbin Spacer (Long Version)
- ① 1 x M12 x 95mm Caphead
- K 2 x M12 x 105mm Caphead
- L 2 x M12 x 120mm Caphead















































































































39

































It is recommended that periodic inspections are made to ensure that all bolts are tightend to the specified torque settings.

Should the bike be involved in an accident a thorough inspection should be made and any components that have taken an impact, no matter how small, be replaced





www.evotech-performance.com