


www.evotech-performance.com
Multistrada V4 Radiator Guard
Installation Instructions


## **Installation Instructions**





## Kit Contents PRN015299


- A 2 x Short Spacer
- B 2 x Long Spacer
- © 10 x M5 x 8mm Button Head Bolts
- D 14 x Rubber Bungs






























Repeat for Left & Right

Locate round holes amongst hexagons.

Push Rubber Spacer through from the back of the guard so Hexagonal shape sits on the front face



















Locate round holes amongst hexagons.


Push Rubber Spacer through from the back of the guard so Hexagonal shape sits on the front face


























## 🔨 ESSENTIAL CHECKS 🔨



It is recommended that periodic inspections are made to ensure that dirt and debris have not become trapped between the guard and the radiator/oil cooler. Such dirt and debris would reduce the cooling efficiency of the radiator/oil cooler.

It is recommended that periodic inspections are made to ensure that all fixings are fully tightend.





www.evotech-performance.com